

Alarm Signal:	One (1) sound signal every 15 seconds for 5 minutes.
Indicates:	The cooker guard warns that the timer is in the last 5 minutes.
Action:	Push the button to reset timer.
Alarm Signal:	One (1) sound signal rapidly, and that change when you rotate the sensor.
Indicates:	Placement assistance when installing the sensor.
Action:	Adjust the sensor so that the sensor eye points in the center of the stove. See installation of sensor.
Alarm Signal:	Two (2) sound signals every 5 minutes.
Indicates:	Battery change is needed.
Action:	Replace the battery. Note! Make sure you have a new battery available first (1 x CR123A).
Alarm Signal:	Three (3) sound signals every 5 seconds and a fixed red light between the signals.
Indicates:	Over heating.
Action:	Lower the temperature or press the button to temporarily approve too high temperature.
Alarm Signal:	Three (3) sound signals every 30 seconds.
Indicates:	Automatically switched off due to overtemperature.
Action:	Lower the temperature and press the button to get power to the stove again.
Alarm Signal:	Five (5) sound signals during 5 seconds.
Indicates:	The sensor is not in its bracket.
Action:	Place the sensor back into mounting bracket and press the button.

NO RESPONSE

Indicates:	No power on stove.
Action:	Push button. Note! If this doesn't work, try to replace the battery (1 x CR123A).


EMERGENCY MODE

In case of problems with the stove that you cannot solve, you can activate emergency mode which provides power to the stove for 12 hours (repeatable for 12 new hours). **NB All security features are disabled during this period. Take the time to contact an electrician to fix the problem.**

To enable emergency mode:
Switch the main fuse for the stove in the fuse box
off/on 3 times with at least 1 second gap within 10 seconds.

Temporary extended user time

Push button for 10 seconds to get extended operating time (two beeps).
Push button for 10 seconds again to get normal operating time (one beep).
See user manual for details.



Alarmsignal:	Ett (1) lydsignal hvert 15. sekund i 5 minutter.
Årsak:	Komfyrvakten varsler at timeren er inne i de siste 5 minuttene.
Tiltak:	Trykk på knappen for å starte timeren på nytt.
Alarmsignal:	Ett (1) lydsignal hurtig, og som endres når du roterer på sensor.
Årsak:	Plasseringshjelp ved montering av sensor.
Tiltak:	Juster sensoren så sensorøyet peker i senter av platetoppen. Se installasjon av sensor.
Alarmsignal:	To (2) lydsignal hvert 5. minutt.
Årsak:	Batteribytte er nødvendig.
Tiltak:	Bytt batteriet. OBS! Påse at du har nytt batteri tilgjengelig først (1 stk CR123A).
Alarmsignal:	Tre (3) lydsignal hvert 5. sekund og fast rødt lys mellom signalene.
Årsak:	Overtemperatur.
Tiltak:	Senk temperaturen, eller trykk på knappen for å midlertidig godkjenne for høy temperatur.
Alarmsignal:	Tre (3) lydsignal hvert 30. sekund.
Årsak:	Automatisk utkoblet på grunn av overtemperatur.
Tiltak:	Senk temperaturen, og trykk på betjeningsknappen for å få strøm til komfyren igjen.
Alarmsignal:	Fem (5) lydsignal i løpet av 5 sekunder.
Årsaker:	Tamperfunksjon detekterer at sensor er fjernet fra festet.
Tiltak:	Sett sensor tilbake i festet og trykk på knappen.

INGEN RESPONS

Årsak:	Ikke strøm på komfyren.
Tiltak:	Trykk på knappen. OBS! Dersom dette ikke virker, prøv å bytt batteri (1 stk CR123A).

NØDMODUS

Ved problemer med komfyrvakten som du ikke kan løse, kan du aktivere nødmodus som gir strøm til komfyren i 12 timer (kan gjenås igjen for 12 nye timer). **OBS! Alle sikkerhetsfunksjoner er deaktivert i denne perioden. Bruk tiden til å kontakte en elektriker for å løse problemet.**

For å aktivere nødmodus:
Slå av og på sikringen til komfyren 3 ganger med minst 1 sekunds mellomrom i løpet av 10 sekunder.

Midlertidig forlenget brukstid

Timeren (nedtellingsuret) kan midlertidig forlenges ved å trykke inn knappen i 10 sekunder (2 pip). Hold inn knapp nye 10 sekunder for normal brukstid (1 pip). Se bruksanvisning for detaljer.

